


**MULTIDRAIN UV 600**

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar  
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



①	Blindflansch	Blind flange	<b>JP48921</b>
②	KT-Schalter	KT-switch	<b>JP48881</b>
③	Stopfen	Plug	<b>JP48887</b>
④	Schraubensatz	Screw set	<b>JP48899</b>
⑤	Lagersatz	Bearing set	<b>JP48893</b>
⑥	Abdeckung	Cover	<b>JP48900</b>
⑦	Verschluss	Plug	<b>JP48882</b>
⑧	Doppelmantel	Double jacket	
	UV 620-625		<b>JP48885</b>
	UV 635		<b>JP48886</b>
⑨	Deckel	Plug	
	1 Loch	1 hole	<b>JP48891</b>
	2 Loch	2 hole	<b>JP48892</b>
⑩	Dichtungssatz	Seal set	<b>JP48898</b>
⑪	Rotorwelle	Rotor shaft	
	UV 620-625		<b>JP48894</b>
	UV 635		<b>JP48895</b>
⑫	Stator + Gehäuse	Stator + Housing	
	620-1		<b>JP48890</b>
	620-3, 625-3		<b>JP48888</b>
	635-3		<b>JP48889</b>
⑬	Leitung	Cable	
	230 V, 620-1		<b>JP48883</b>
	400 V, 6xx-3		<b>JP48884</b>
⑭	Lagerflansch	Bearing flange	<b>JP48901</b>
⑮	Gleitringsdicht.satz	Mech. seal set	<b>JP48902</b>
⑯	Dichtungsdeckel	Seal cover	<b>JP48903</b>
⑰	Ölschraube	Oil screw	<b>JP48904</b>
⑱	LaufRad	Impeller	
	UV 620		<b>JP48905</b>
	UV 625		<b>JP48906</b>
	UV 635		<b>JP48907</b>
⑲	Ringgehäusedeckel	Volute casing cover	<b>JP48908</b>
⑳	Kondensator	Capacitor	<b>JP48879</b>
㉑	Platine	PCB	
	UV 620-1		<b>JP48897</b>
	UV 620-1S		<b>JP50263</b>
	UV 6xx-3		<b>JP48896</b>
㉒	Siebfuß	Strainer base	<b>JP48914</b>
㉓	SchaltSchütz	Contacteur	<b>JP48880</b>
--	Motorschutzstecker 230V	Motor protection plug 230V	<b>JP50290</b>