



Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar  
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



①	Motorschutz	Motor protection	
	151 ES	Schuko-plug	<b>JP40264</b>
	151 DS	CEE-plug	<b>JP44750</b>
	251 DS	CEE-plug	<b>JP44751</b>
②	Schwimmer	Float	<b>JP46266</b>
③	Leitung	Cable	
	E		<b>JP46260</b>
	D		<b>JP46259</b>
④	Stator + Gehäuse	Stator + Housing	
	E		<b>JP46268</b>
	D		<b>JP46267</b>
⑤	Rotorwelle	Rotor shaft	
	E		<b>JP46271</b>
	D		<b>JP46270</b>
⑥	Lagersatz	Bearing set	<b>JP46269</b>
⑦	Pumpengehäuse	Pump casing	<b>JP46277</b>
⑧	Dichtungssatz	Seal set	<b>JP46272</b>
⑨	Laufrad	Impeller	
	151		<b>JP46274</b>
	251		<b>JP46275</b>
⑩	Schleißplatte	Wear plate	<b>JP46273</b>
⑪	Ölschraube	Oil screw	<b>JP46046</b>
⑫	Gleitringdichtung	Mechanical seal	<b>JP46043</b>
⑬	Schraubensatz	Screw set	<b>JP46011</b>
⑭	Siebfuß	Strainer base	<b>JP46276</b>
⑮	1l Öl	1l Oil	<b>JP48236</b>



①	CEE Motorschutz	CEE plug	JP44751
②	Schwimmer	Float	JP46266
③	Leitung	Cable	JP46259
④	Stator + Gehäuse	Stator + Housing	JP46267
⑤	Lagersatz	Bearing set	JP46269
⑥	Rotorwelle	Rotor shaft	JP46270
⑦	Pumpengehäuse	Pump casing	JP46279
⑧	Dichtungssatz	Seal set	JP46272
⑨	Laufrad	Impeller	JP46454
⑩	Deckel	Cover	JP46050
⑪	Ölschraube	Oil screw	JP46046
⑫	Gleitringdichtung	Mechanical seal	JP46043
⑬	Schraubensatz	Screw set	JP46011
⑭	Füße	Feet	JP46047
⑮	1l Öl	1l Oil	JP48236