


## COMPLI 1500 HL- COMPLI 2500 HL

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar  
 Varaoasat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



①	Niveauschaltung	Level control	<b>JP47306</b>
②	Dichtung Niveauerfassung	Seal level control	<b>JP50479</b>
③	Steuerung	Control unit	
	HighLogo 2-46P (25/4)		<b>JP50511</b>
	HighLogo 2-610P (35/2, 35/4)		<b>JP50512</b>
	HighLogo 2-610PD (55/2, 55/4)		<b>JP50513</b>
	HighLogo 5-1016P (75/2, 75/4)		<b>JP50514</b>
	HighLogo 5-1620P (100/2)		<b>JP50515</b>
	HighLogo 5-2532P (200/2)		<b>JP50516</b>
④	Platine	Circuit board	<b>JP50176</b>
⑤	Klemmflansch	Clamping flange	<b>JP43713</b>
⑥	Überschiebmuffe	Collar	<b>JP46814</b>
⑦	Wartungsdeckel	Service lid	<b>JP42798</b>
⑧	Pumpenlüftung	Pump ventilation	<b>JP43732</b>
⑨	Behälter	Tank	<b>JP45945</b>
⑩	Klemmflansch	Clamping flange	<b>JP43713</b>
⑪	Dichtungssatz	Seal set	<b>JP46074</b>
⑫	Auftriebssicherung	Anti float set	<b>JP43716</b>
⑬	Stütze	Support	
	B2		<b>JP47669</b>
	B5		<b>JP47665</b>
	B6		<b>JP47666</b>
	C1		<b>JP47667</b>
	C5		<b>JP47668</b>
⑭	Pumpenfüße	Pump base	<b>JP46075</b>
⑮	Elast. Verbindung	Elastic connection	<b>JP46009</b>
⑯	Pumpe	Pump	
	25/4 C1		<b>JP47651</b>
	35/4 C1		<b>JP47652</b>
	55/4 C5		<b>JP47653</b>
	75/4 C5		<b>JP47654</b>
	75/4 B6		<b>JP47655</b>
	35/2 B2		<b>JP47656</b>
	55/2 B2		<b>JP47657</b>
	75/2 B5		<b>JP47658</b>
	100/2 B5		<b>JP47659</b>
	200/2 B6		<b>JP47660</b>
⑰	Fußkrümmer	Bend receiver base	<b>JP47661</b>